

Power supply and control kit for Skywatcher EQ8 PRO mount

The 1st full package “plug & play” for powering and controlling an EQ8 PRO mount

Includes:

- 1 pc Switching power supply
- 1 pc 4-way patch cable (input 5.5/2.1mm – 3 outputs in 5.5/2.1mm and 1 input in 5.5/2.5mm)
- 1 pc Adapter 5.5/2.5mm to 2-pin DIN plug
- 1 pc EQDir cable for Skywatcher EQ8 PRO mount to use with ASCOM EQMOD plugin



1. A **high quality switching power supply** provided with accessories for specifically powering a Skywatcher EQ8 PRO mount (2-pin DIN socket)
2. Mount controlling with **special EQDir cable** (ASCOM EQMOD plugin)
3. **Bonus** : **4-way patch cable** for powering several devices with a power supply voltage 12V Direct Courant

Technical features

<p><u>Switching Power Supply</u></p>	<p>Input: 110-240V AC – 1.3A - 50/60 Hz Input cable 2 contacts (phase / neutral) with European plug Cable length: 1,20m</p> <p>Output: 12V/DC – 10A Jack connector 5.5/2.5mm right angle Male Cable length: 1.40m</p> <p>Adapter: 5.5/2.5mm Female to 5.5/2.1mm Male to be able to use the 4-way patch cable</p> 
<p><u>4-way patch cable</u></p>	<p>For powering other devices such as cooled CCD camera, focuser motor, ...</p> <p>Input: 1 input 5.5/2.1mm Female</p> <p>Outputs : 3 outputs 5.5/2.1mm Male 1 output 5.5/2.5mm Male for powering a Skywatcher EQ8 PRO mount</p> 

Adapter 5.5/2.5mm Female to 2-pin DIN Female plug

Specific power supply connector for EQ8 PRO mount (2-pin DIN Female plug)



EQDir cable for EQ8 PRO mount

To use with ASCOM EQMOD plugin: could be downloaded from here http://sourceforge.net/projects/eq-mod/files/EQASCOM/EQASCOM_V127I_Setup.exe/download

Chip: FTDI

Input: RJ45

Output: USB

Length: 1.80m

Compatibility: Windows XP, Vista, Windows 7, 8, 8.1 x86/x64

